

elvace

CM^eSERIES
The everything meter.

Report Templates
Description Template
2005

CMe2100, CMi2110, CMi2120, CMi2130

FTP event report - single file - plain

Contents

CONTENTS	2
1 DOCUMENT NOTES	3
1.1 COPYRIGHT AND TRADEMARK.....	3
1.2 CONTACTS.....	3
2 USING THIS DOCUMENT	4
2.1 PURPOSE AND AUDIENCE	4
2.2 MODELS	4
2.3 ADDITIONAL AND UPDATED INFORMATION.....	4
3 REPORT FORMAT	5
3.1 FILENAME	5
3.2 FILE CONTENTS	5
3.3 DEFINITIONS	6
4 DOCUMENT HISTORY	7
4.1 DOCUMENT SOFTWARE AND HARDWARE APPLIANCE.....	7
5 REFERENCES	8
5.1 REFERENCES	8
5.2 TERMS AND ABBREVIATIONS	8
5.2.1 <i>Number representation</i>	8

1 Document notes

All information in this manual, including product data, diagrams, charts, etc. represents information on products at the time of publication, and is subject to change without prior notice due to product improvements or other reasons. It is therefore recommended that customers contact Elvaco AB for the latest product information before purchasing a CMe/CMi Series product.

The documentation and product are provided on an "as is" basis only and may contain deficiencies or inadequacies. Elvaco AB takes no responsibility for damages, liabilities or other losses by using this product.

1.1 Copyright and Trademark

© 2010, Elvaco AB. All rights reserved. No part of the contents of this manual may be transmitted or reproduced in any form by any means without the written permission of Elvaco AB. Printed in Sweden.

CMe/CMi Series is a trademark of Elvaco AB, Sweden.

1.2 Contacts

Elvaco AB Headquarter

Energigatan 9
434 37 Kungsbacka
SWEDEN

Phone: +46 300 30250

Fax: +46 300 18440

E-Mail: info@elvaco.com

Elvaco AB Technical Support

Phone: +46 300 434300

E-Mail: support@elvaco.se

Online: <http://www.elvaco.com>

2 Using this document

2.1 Purpose and Audience

This document describes the contents of the report information created from report template 2005. Use this document together with Report Template Reference Information for complete understanding of this report template contents.

For customer specific templates, please contact Elvaco AB.

2.2 Models

CMe2100,CMi2110,CMi2120,CMi2130

2.3 Additional and updated information

Latest documentation version is available on Elvaco web site at <http://www.elvaco.com>.

3 Report format

This report contains event information sent from the product. Example of events are firmware updated and rebooted unexpectedly. On execution of this report, one file with event information is sent to the FTP Server.

3.1 Filename

Filename of the report data file sent to server is in the following format:

<serial-number>_eventreport_<time>_<report-id>.csv.

Example of a file sent from a product with serial number 0006123456 at 2010-09-01 01:00:00:

0006123456_eventreport_20100901010000_2005.csv.

3.2 File contents

The file contains a column header line and key value pairs of information. See Table 1 for column line information definition and Table 2 for value line definition.

Column index (0 = first column)	Column contents	Description
0	#	Fixed value indicating column information line.
1	key	Fixed value
2	value	Fixed value

Table 1 Column header line definition

Column index (0 = first column)	Column contents	Description
0	<key>	Key name Can be one of the following: time serial-number event module-revision sw-version prepaid-infoavailable prepaid-credits prepaid-currency prepaid-expiredate
1	<value>	Value
Example of file contents for firmware update event		

```
#key;value  
time;2010-09-01 00:01:02  
serial-number;0006123456  
event;fwupdate  
module-revision;1.100
```

Table 2 Value line definition and example file

3.3 Definitions

Type	Value	Description
Column delimiter	Semi-colon “;”	The field separator
Decimal point delimiter	Not used	Decimal separator character
End of line character(s)	CRLF (0x0D0A)	End of every line, before starting a new line.

Table 3 Definitions

4 Document History

Version	Date	Description	Author
1.0	2010-09-27	First release	David Vonasek

4.1 Document software and hardware appliance

Type	Version	Date	Comments
Hardware	-	-	-
Software	>1.1.5	2010-03	

5 References

5.1 References

- [1] CMe Series User's Manual
- [2] CMi2110 User's Manual
- [3] CMi2120 User's Manual
- [4] CMi2130 User's Manual
- [5] Report Template Description [n], where n is the report template id

5.2 Terms and Abbreviations

Abbreviation	Description

5.2.1 Number representation

Decimal numbers are represented as normal number, i.e. 10 (ten).

Hexadecimal numbers are represented with prefix 0x, i.e. 0x0A (ten)

Binary numbers are represented with prefix 0b, i.e. 0b00001010 (ten)